

## instructions, warranties and other collateral documents are subject to change at the sole discretion of Horizon Hobby. Inc. For up-to-date product literature, visit horizonhobby.com and click on the support tab for this product

### ing of Special Langua *i*ing terms are used thr

- re to indicate variou levels of potential harm when operating this product: **NOTICE:** Procedures, which if not properly followed, create a possibility of physical property damage AND a little or no possibility of injury
- **CAUTION:** Procedures, which if not properly followed, create the probability of

physical property damage AND a possibility of serious injury. WARNING: Procedures, which if not properly followed, create the probability of property damage, collateral damage, and serious injury OR create a high probability

of superficial injury. **WARNING:** Read the ENTIRE instruction manual to become familiar with the features of the product before operating. Failure to operate the product correctly can result in damage to the product, personal property and cause

## serious injury.

✓ Included Items

**OPTIONAL ACCESSORIES** 

OYN4012 - DC Power Cord

FEATURES

DYN5032 - Balancing Adapter Board

capacities and cell counts

Pb battery voltage of 2 to 20V

Built-in 50W discharger

Built-in balance circuit

This is a sophisticated hobby product. It must be operated with caution and common sense and requires some basic mechanical ability. Failure to operate this Product in a safe and responsible manner could result in injury or damage to the product or other property. This product is not intended for use by children without direct adult supervision. Do not attempt disassembly, use with incompatible components or augment product in any way without the approval of Horizon Hobby. Inc. This manual contains instructions for safety, operation and maintenance. It is essential to read and follow all the instructions and warnings in the manual, prior to assembly, setup or use, in order to operate correctly and avoid damage or serious injury. Age Recommendation: Not for children under 14 years. This is not a toy.

## SAFETY PRECAUTIONS AND WARNINGS

JST\_XH Balance adapter (2)

- **WARNING:** Failure to exercise caution while using this product and comply with the following warnings could result in product malfunction, electrical issues, excessive heat, FIRE, and ultimately injury and property damage.
- Never leave the power supply, charger and battery unattended during use. Never attempt to charge dead, damaged or wet battery packs.

### Never attempt to charge a battery pack containing different types of batteries. Never allow children under 14 years of age to charge battery packs Never charge batteries in extremely hot or cold places or place in direct sunlight

- Never charge a battery if the cable has been pinched or shorted. Never connect the charger if the power cable has been pinched or shorted.
- Never connect the charger to an automobile 12V battery while the vehicle is runnina.
- Never attempt to dismantle the charger or use a damaged charger. Never attach your charger to both an AC and a DC power source at the same time.
- Never connect the input jack (DC input) to AC power. Always use only rechargeable batteries designed for use with this type of charger Always inspect the battery before charging.
- Always keep the battery away from any material that could be affected by heat. Always monitor the charging area and have a fire extinguisher available at all times.
- Always end the charging process if the battery becomes hot to the touch or starts to change form (swell) during the charge process. Always connect the charge cable to the charger first, then connect the battery to
- avoid short circuit between the charge leads. Reverse the sequence when disconnecting. • Always connect the positive red leads (+) and negative black leads (-) correctly.
- Always disconnect the battery after charging, and let the charger cool between charges.
- Always charge in a well-ventilated area. Always terminate all processes and contact Horizon Hobby if the product malfunctions

### WARNING: Never leave charger unattended, exceed maximum charge rate, charge with non-approved batteries or charge batteries in the wrong mode. Failure to comply may result in excessive heat, fire and serious injury.

**CAUTION:** Always ensure the battery you are charging meets the pecifications of this charger and that the charger settings are correct. Not doing so can result in excessive heat and other related product malfunctions, which can lead to user injury or property damage. Please contact Horizon Hobby or an authorized retailer with compatibility questions.

over-temperature protection

Storage and Fast Charge modes





# **3** LI-FE BALANCE CHARGING

Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial to To select values other than the existing parameters: locate the PROGRAM SELECT LiFe BATT screen. Press the Jog Dial to go into this • Press the Jog Dial so the charge current value (A) flashes

Rotate the Jog Dial to go to the LiFe BALANCE screen and set charging param-• Press the Jog Dial to save the value and the voltage value (B) flashes eters. The charging amperage (A) can be set between 0.1 and 10.0A. Voltage (B) is • Rotate the Jog Dial to INCREASE OR DECREASE the voltage (and # of cells in dependent on the number of cells in series. For example, with Li-Fe batteries these values can be from 3.3V (for 1S batteries) to 19.8V (for 6S batteries).



# LI-FE CHARGING

- Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial to To select values other than the existing parameters: locate the PROGRAM SELECT LiFe BATT screen. Press the Jog Dial to go into this • Press the Jog Dial so the charge current value (A) flashes
- Rotate the Jog Dial to go to the LiFe CHARGE screen and set charging parameters. Press the Jog Dial to save the value and the voltage value (B) flashes The charging amperage (A) can be set between 0.1 and 10.0A. Voltage (B) is • Rotate the Jog Dial to INCREASE OR DECREASE the voltage (and # of cells in dependent on the number of cells in series. For example, with Li-Fe batteries these series (C) values can be from 3.3V (for 1S batteries) to 19.8V (for 6S batteries).



# LI-FE FAST CHARGING

Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial to locate the PROGRAM SELECT LiFe BATT screen. Press the **Jog Dial** to go into this

Rotate the Jog Dial to go to the LiFe FAST CHG screen and set charging parameters. The charging amperage (A) can be set between 0.1 and 10.0A. Voltage (B) is dependent on the number of cells in series. For example, with Li-Fe batteries these values can be from 3.3V (for 1S batteries) to 19.8V (for 6S batteries).

Near the end of a standard charging cycle, the charger switches from Constant Cur- To select values other than the existing parameters: rent (CC) mode to Constant Voltage (CV) mode to slowly "top off" the current in the • Press the Jog Dial so the charge current value (A) flashes battery as close as possible to the maximum capacity.

In Fast Charge, the CV mode is eliminated in order to greatly shorten the charging time; however, the final capacity of the battery will be less than what you would get • Rotate the **Jog Dial** to INCREASE OR DECREASE the voltage (and # of cells in using the standard charge method.

- **D** LI-FE STORAGE CHARGING
- Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial to To select values other than the existing parameters: locate the PROGRAM SELECT LiFe BATT screen. Press the Jog Dial to go into this • Press the Jog Dial so the charge current value (A) flashes
- Rotate the Jog Dial to go to the LiFe STORAGE screen and set charging parameters. The charging amperage (A) can be set between 0.1 and 10.0A. Voltage (B) is • Rotate the Jog Dial to INCREASE OR DECREASE the voltage (and # of cells in dependent on the number of cells in series. For example, with Li-Fe batteries these values can be from 3.3V (for 1S batteries) to 19.8V (for 6S batteries). If you don't plan on using your battery for a long time, it is best to charge (or
- discharge) the battery to its optimal storage voltage and capacity. LiFe STORAGE

19,8V(6<u>S</u>)

If no parameters are flashing, you can rotate the Jog Dial to select another program such as CHARGE, FAST CHG, STORAGE or DISCHARG

Press the Jog Dial to save the voltage value

• Rotate the Jog Dial to INCREASE OR DECREASE the charge current value

- To start charging, press and hold the Jog Dial for 3 seconds.









• Press the **Jog Dial** to save the voltage value If no parameters are flashing, you can rotate the **Jog Dial** to select another program such as BALANCE, FAST CHG, STORAGE or DISCHARGE. To start charging, press and hold the Jog Dial for 3 seconds.

• Rotate the **Jog Dial** to INCREASE OR DECREASE the charge current value

**CAUTION:** If at any time during the charge process the battery pack becomes hot or begins to puff, disconnect the battery immediately and discontinue the charge process as batteries can cause fire, collateral damage and injuries.



- Rotate the **Jog Dial** to INCREASE OR DECREASE the charge current value
- Press the **Jog Dial** to save the value and the voltage value **(B)** flashes
- series (C)) • Press the **Jog Dial** to save the voltage value
- If no parameters are flashing, you can rotate the **Jog Dial** to select another program such as CHARGE, BALANCE, STORAGE or DISCHARGE. To start charging, press and hold the **Jog Dial** for 3 seconds.

- Rotate the **Jog Dial** to INCREASE OR DECREASE the charge current value
- Press the **Jog Dial** to save the value and the voltage value **(B)** flashes
- series (C))
- Press the **Jog Dial** to save the voltage value
- If no parameters are flashing, you can rotate the **Jog Dial** to select another program such as CHARGE, BALANCE, FAST CHG or DISCHARGE.

To start charging, press and hold the **Jog Dial** for 3 seconds.

35	BATTERY MEMORY
36	SYSTEM SET
a	REST TIME
b	SAFETY TIMER
C	CAPACITY CUTOFF
d	KEY BEEP/BUZZER
е	INPUT POWER LOW CUTOFF
f	EXTERNAL AND INTERNAL TEMPERATURES
g	RESET FACTORY SETTINGS
— h	VERSION
37	LI BATTERY VOLTAGE CHECKER OPERATION -
	USING THE BALANCE ADAPTER PORT
38	USB ACCESSORY CHARGER OPERATION
	(COMPATIBLE WITH iPhone AND iPod DEVICES)
39	TROUBLESHOOTING GUIDE

L 2	iPo .0A	BALANCE 7.4V(2S)	
200	the Mod	<b>In koy</b> to go back to the main m	0

¢ 2.0A 22:43	₽ 12.59U 01082	А. В.	A Li-Fe battery pack is balance charging Battery pack has 3 cells in series	
F	É	-		
is 2.0A (2000mAh)				

**F.** Time elapsed since the charge process started is 22:43 (22 minutes and 43

parameter messages on the LCD screen, including: End Voltage, Input Power Voltage, External & Internal Temperature, Temperature Cutoff, Safety Timer Status and

Rotate the **Jog Dial** clockwise to show the charge voltages for each cell. Press the Jog Dial at any time to return to the Charge Monitor screen. The charger signals when the charging (or discharging) process is complete (if Buzzer is set to ON).

battery types using these programs will result in damage to the battery or

**A.** A Li-Po battery pack is balance charging B. Battery pack has 3 cells in series

During charging, the Jog Dial can be rotated counterclockwise to show several parameter messages on the LCD screen, including: End Voltage, Input Power Volt-

Rotate the **Jog Dial** clockwise to show the charge voltages for each cell. Press the **Jog Dial** at any time to return to the Charge Monitor screen. The charger signals when the charging (or discharging) process is complete (if Buzzer is set to ON).

charging and discharging of Li-Po battery packs. The charging of other battery types using these programs will result in damage to the battery or

 Rotate the Jog Dial to INCREASE OR DECREASE the charge current value Press the Jog Dial to save the value and the voltage value (B) flashes

If no parameters are flashing, you can rotate the **Jog Dial** to select another program

If no parameters are flashing, you can rotate the Jog Dial to select another program

**CAUTION:** If at any time during the charge process the battery pack becomes hot or begins to puff, disconnect the battery immediately and discontinue the charge process as batteries can cause fire, collateral damage and injuries.

## LI-PO FAST CHARGING

**18** LI-PO STORAGE CHARGING

Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial to locate the PROGRAM SELECT LiPo BATT screen. Press the Jog Dial to go into this

Rotate the Jog Dial to go to the LiPo FAST CHG screen and set charging parameters. The charging amperage (A) can be set between 0.1 and 10.0A. Voltage (B) is dependent on the number of cells in series. For example, with Li-Po batteries these values can be from 3.7V (for 1S batteries) to 22.2V (for 6S batteries).

Near the end of a standard charging cycle, the charger switches from Constant Current (CC) mode to Constant Voltage (CV) mode to slowly "top off" the current in the battery as close as possible to the maximum capacity.

time; however, the final capacity of the battery will be less than what you would get using the standard charge method.

values can be from 3.7V (for 1S batteries) to 22.2V (for 6S batteries).

discharge) the battery to its optimal storage voltage and capacity.

\_iPo STORAGE

If you don't plan on using your battery for a long time, it is best to charge (or

# LiPo FAST CHG 4.0A 7,4U(2S) To select values other than the existing parameters:

• Press the Jog Dial so the charge current value (A) flashes

• Rotate the Jog Dial to INCREASE OR DECREASE the charge current value • Press the **Jog Dial** to save the value and the voltage value **(B)** flashes

In Fast Charge, the CV mode is eliminated in order to greatly shorten the charging • Rotate the Jog Dial to INCREASE OR DECREASE the voltage (and # of cells in

series (C)) • Press the **Jog Dial** again to save the voltage value

If no parameters are flashing, you can rotate the **Jog Dial** to select another program such as CHARGE, BALANCE, STORAGE or DISCHARGE. To start charging, press and hold the **Jog Dial** for 3 seconds.

Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial to To select values other than the existing parameters:

locate the PROGRAM SELECT LiPo BATT screen. Press the Jog Dial to go into this • Press the Jog Dial so the charge current value (A) flashes

To start charging, press and hold the **Jog Dial** for 3 seconds.

such as CHARGE, BALANCE, FAST CHG or STORAGE.

To start discharging, press and hold the Jog Dial for 3 seconds.

- Rotate the Jog Dial to INCREASE OR DECREASE the charge current value
- Press the **Jog Dial** to go to the LiPo STORAGE screen and set charging param• Press the **Jog Dial** to save the value and the voltage value (**B**) flashes eters. The charging amperage (A) can be set between 0.1 and 10.0A. Voltage (B) is • Rotate the Jog Dial to INCREASE OR DECREASE the voltage (and # of cells in
- dependent on the number of cells in series. For example, with Li-Po batteries these series (C) • Press the **Jog Dial** to save the voltage value

If no parameters are flashing, you can rotate the Jog Dial to select another program such as CHARGE, BALANCE, FAST CHG or DISCHARGE.

Rotate the Jog Dial to INCREASE OR DECREASE the discharge current value

# **24** NI-MH RE-PEAK CHARGING

Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial To select a value other than the existing param to locate the PROGRAM SELECT NIMH BATT screen. Press the Jog Dial to go into • Press the Jog Dial so the re-peak value (A) this menu.

Rotate the **Jog Dial** to go to the NiMH RE-PEAK screen and set re-peak parameters • Press the **Jog Dial** to save the value to a value of between 1 and 3.

NIMH RE-PEAK

# **25** <u>NI-MH CYCLE CHARGING</u>

**26** <u>NI-CD BATTERIES</u>

(information may vary).

27 NI-CD CHARGING



Rotate the **Jog Dial** to go to the NiMH CYCLE screen and set charge/discharge cycle count parameters.

The battery can be put through a series of charge/discharge cycles using this program. Cycling Ni-MH batteries can increase capacity and rejuvenate neglected If no parameters are flashing, you can rotate th batteries. Discharge capacity and average battery voltage help you compare batter- such as CHARGE, Auto CHARGE, DISCHARGE o ies for the best run time and power.



DISCHARGE, RE-PEAK or CYCLE) to do what your battery needs.

E

**C.** Voltage being applied to the battery is currently 7.59V D. Present charge level of the battery is 1082 mAh

**E.** Time elapsed since the charge process started is 22:43

The charging amperage (A) can be set between 0.1 and 10.0A.

NiCd CHARGE

CURREN

CURRENT

28 NI-CD AUTO CHARGING

this menu

Correctly connect your Ni-Cd battery to the charger. Press the Jog Dial and adjust

the charging parameters as needed. Press and hold the **Jog Dial** (approximately 3

**C A.** A Ni-Cd battery pack is

1.0A

1.8A

seconds) until the screen changes to start the battery check/charge sequence.

After confirmation, charging starts and information will show on the LCD screen

NICd 2.0A 7.59U CHG 022:43 01082 B. Charging rate is 2.0A (2000mAh)

D

During charging, the **Jog Dial** can be rotated counterclockwise to show several

# Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial to parameter messages on the LCD screen, include locate the PROGRAM SELECT NiCd BATT screen. Press the Jog Dial to select NiCd. Voltage, External & Internal Temperature, Tempe Rotate the Jog Dial to go to one of the control screens (CHARGE, Auto CHARGE, and Capacity Cutoff. The charger signals when

- Press the **Mode key** until you reach the 9 main menus, then rotate the **Jog Dial** to To select values other than the existing parameters: locate the PROGRAM SELECT LiPo BATT screen. Press the Jog Dial to go into this • Press Jog Dial so the discharge current value (A) flashes Rotate the **Jog Dial** to go to the LiPo DISCHARGE screen and set discharging pa-•• Press the **Jog Dial** to save the value and the voltage value (**B**) flashes
- rameters. The discharging amperage (A) can be set between 0.1 and 5.0A. Voltage Rotate the Jog Dial to INCREASE OR DECREASE the voltage (and # of cells in (B) is dependent on the number of cells in series. For example, with Li-Po batteries series (C) these values can be from 3.7V (for 1S batteries) to 22.2V (for 6S batteries). Press Jog Dial to save the voltage value A battery's capacity can be verified by discharging it to its minimum voltage level If no parameters are flashing, you can rotate the **Jog Dial** to select another program

and measuring the current as the battery is discharged



# **2**() <u>NI-MH BATTERIES</u>

**19** <u>LI-PO DISCHARGING</u>

Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial During charging, the Jog Dial can be rotated counterclockwise to show several to locate the PROGRAM SELECT NIMH BATT screen. Press the Jog Dial to select

Rotate the **Jog Dial** to go to one of the control screens (CHARGE, Auto CHARGE, DISCHARGE, RE-PEAK or CYCLE) to do what your battery needs. Correctly connect your Ni-MH battery to the charger. Press the Jog Dial and adjust

the charging parameters as needed. Press and hold the **Jog Dial** (approximately 3 seconds) until the screen changes to start the battery check/charge sequence. After confirmation, charging starts and information will show on the LCD screen (information may vary)



- D. Present charge level of the battery is 1082 mAh
- E. Time elapsed since the charge process started is 22:43

# 21 NI-MH CHARGING

Press the **Mode key** until you reach the 9 main menus, then rotate the **Jog Dial** To select a value other than the existing parameter: to locate the PROGRAM SELECT NIMH BATT screen. Press the Jog Dial to go into

Rotate the Jog Dial to go to the NIMH CHARGE screen and set charging parameters. The charging amperage (A) can be set between 0.1 and 10.0A.

NIMH CHARGE CURRENT 1.0A

# 22 NI-MH AUTO CHARGING

Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial To select a value other than the existing paramete to locate the PROGRAM SELECT NIMH BATT screen. Press the Jog Dial to go into • Press the Jog Dial so the charge current value (A) flashes this menu.

Rotate the Jog Dial to go to the NiMH Auto CHARGE screen and set charging parameters. The charging amperage (A) can be set between 0.1 and 10.0A.



# **23** <u>NI-MH DISCHARGING</u>

Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial To select a value other than the existing parameter to locate the PROGRAM SELECT NIMH BATT screen. Press the Jog Dial to go into • Press the Jog Dial so the discharge current value (A) flashes this menu.

Rotate the Jog Dial to go to the NiMH DISCHARGE screen and set discharging parameters. The discharging amperage (A) can be set between 0.1 and 5.0A. A battery's capacity can be verified by discharging it to its minimum voltage level • Press the **Jog Dial** to save the voltage value and measuring the current as the battery is discharged. The discharge level can be If no parameters are flashing, you can rotate the **Jog Dial** to select another program set from 0.1 to 25.2V.



- Rotate the **Jog Dial** to INCREASE OR DECREASE the charge current value • Press the Jog Dial to save the value

• Rotate the Jog Dial to INCREASE OR DECREASE the discharge current value

• Press the **Jog Dial** to save the value and the cutoff voltage value **(B)** flashes • Rotate the Jog Dial to INCREASE OR DECREASE the cutoff voltage

If no parameters are flashing, you can rotate the Jog Dial to select another program

such as CHARGE, DISCHARGE, RE-PEAK or CYCLE.

such as CHARGE, Auto CHARGE, RE-PEAK or CYCLE.

To start discharging, press and hold the Jog Dial for 3 seconds

To start charging, press and hold the Jog Dial for 3 seconds.

parameter messages on the LCD screen, including: Ni-MH Sensitivity, Input Power Voltage, External & Internal Temperature, Temperature Cutoff, Safety Timer Status and Capacity Cutoff. The charger signals when the charging (or discharging) process is complete (if Buzzer is set to ON).

**CAUTION:** The Ni-MH program menus are to be used ONLY for the charging and displayering activity of the transmission of the t charging and discharging of Ni-MH battery packs. The charging of other battery types using these programs will result in damage to the battery or

CAUTION: Using a charge rate that is not compatible with the battery capacities may result in damage or malfunction of the charger or

- Press the Jog Dial so the charge current value (A) flashes • Rotate the **Jog Dial** to INCREASE OR DECREASE the charge current value
- Press the Jog Dial to save the value
- If no parameters are flashing, you can rotate the **Jog Dial** to select another program Press the **Mode key** until you reach the 9 main menus, then rotate the **Jog Dial** To select a value other than the existing parameters are flashing and the select another program of the sel such as Auto CHARGE, DISCHARGE, RE-PEAK or CYCLE.

To start charging, press and hold the Jog Dial for 3 seconds.







# **30** <u>NI-CD RE-PEAK CHARGING</u>

Press the **Mode key** until you reach the 9 main menus, then rotate the **Jog Dial** To select a value other than the existing parameters of the select a value other than the select a value other the sel to locate the PROGRAM SELECT NiCd BATT screen. Press the Jog Dial to go into • Press the Jog Dial so the re-peak value (A) this menu

Rotate the **Jog Dial** to go to the NiCd RE-PEAK screen and set re-peak parameters • Press the **Jog Dial** to save the value to a value of between 1 and 3.

NiCd RE-PEAK

# **31** <u>NI-CD CYCLE CHARGING</u>

Press the **Mode key** until you reach the 9 main menus, then rotate the **Jog Dial** To select values other than the existing parameters to locate the PROGRAM SELECT NICO BATT screen. Press the Jog Dial to go into • Press the Jog Dial so the cycle type (A) fla this menu Rotate the Jog Dial to go to the NiCd CYCLE screen and set charge/discharge cycle • Press the Jog Dial to save your choice and

count parameters The battery can be put through a series of charge/discharge cycles using this

program. Cycling Ni-Cd batteries can increase capacity and rejuvenate neglected If no parameters are flashing, you can rotate the **Jog Dial** to select another program batteries. Discharge capacity and average battery voltage help you compare batter- such as CHARGE, Auto CHARGE, DISCHARGE or RE-PEAK. ies for the best run time and power.



- Press the **Mode key** until you reach the 9 main menus, then rotate the **Jog Dial** to To select a value other than the existing parameters of the select a value other than the existing parameters and the select locate the PROGRAM SELECT NICd BATT screen. Press the Jog Dial to go into this . Press the Jog Dial so the charge current val • Rotate the Jog Dial to INCREASE OR DECRI Rotate the **Jog Dial** to go to the NiCd CHARGE screen and set charging parameters. • Press the **Jog Dial** to save the value
  - If no parameters are flashing, you can rotate th such as Auto CHARGE, DISCHARGE, RE-PEAK To start charging, press and hold the Jog Dial
- Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial To select a value other than the existing parameters of the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select a value other than the existing parameters and the select and to locate the PROGRAM SELECT NICd BATT screen. Press the Jog Dial to go into . Press the Jog Dial so the charge current va
  - Rotate the Jog Dial to INCREASE OR DECR Press the Jog Dial to save the value
  - If no parameters are flashing, you can rotate the such as CHARGE, DISCHARGE, RE-PEAK or CYC To start charging, press and hold the Jog Dial

**29** <u>NI-CD DISCHARGING</u> NiCd BATT screen. Press the .log Dial to go int to locate the

Rotate the Jog Dial to go to the NiCd Auto CHARGE screen and set charging

parameters. The charging amperage (A) can be set between 0.1 and 10.0A.

NiCd Auto CHARGE

this menu. Rotate the **Jog Dial** to go to the NiCd DISCHARGE screen and set discharging Press the Jog Dial to save the value and the value va parameters. The discharging amperage (A) can be set between 0.1 and 5.0A. Rotate the Jog Dial to INCREASE OR DECR

A battery's capacity can be verified by discharging it to its minimum voltage level • Press the Jog Dial to save the voltage value and measuring the current as the battery is discharged. The discharge level can be If no parameters are flashing, you can rotate th set from 0.1 to 25.2V.



- such as CHARGE, Auto CHARGE, RE-PEAK or C To start discharging, press and hold the Jog Di

  - Rotate the Jog Dial to INCREASE OR DECR
  - If no parameters are flashing, you can rotate th such as CHARGE, Auto CHARGE, DISCHARGE o Press the Jog Dial to go to the next menu.

  - Rotate the Jog Dial to set the cycle type as

  - Rotate the **Jog Dial** to set the cycle count between 1 to 5 • Press the **Jog Dial** to save the cycle count value

To start cycling, press and hold the Jog Dial for 3 seconds.

	22					
	32 PB BATTERIES		37 LI BATTERY VOLTAGE	CHECKER OPERATION - U	SING THE BALANCE	
<ul> <li>Press the Jog Dial so the re-peak value (A) flashes</li> </ul>	Press the <b>Mode key</b> until you reach the 9 main menus, then rotate the <b>Jog Dial</b> to locate the PROGRAM SELECT Pb BATT screen. Press the <b>Jog Dial</b> to select Pb.	B C D A. A Lead Acid battery pack is charging	cell voltages of a Li-Po, Li-Fe or	has the capability to read and Li-lo battery. This voltage cho	display the individua	I his example is for played. The data is
<ul> <li>Rotate the Jog Dial to INCREASE OR DECREASE the value</li> <li>Press the Jog Dial to save the value</li> </ul>	Rotate the <b>Jog Dial</b> to go to one of the control screens (CHARGE or DISCHARGE) to do what your battery needs.	A CHG 022:43 01082 B. Battery pack has 6 cells in series	To use the voltage checker, conn	s powered ON and not charg ect the balance port connec	ing a battery. tor of your Li-Po, Li-Fi	e <b>1</b>
If no parameters are flashing, you can rotate the <b>Jog Dial</b> to select another program such as CHARGE Auto CHARGE DISCHARGE or CYCLE.	The nature of a Lead Acid or Sealed Lead Acid battery is very different from that of Lithium, Ni-MH or Ni-Cd batteries. The output current of a Pb battery is lower than	F = E	or Li-lo battery to the balance ad Adapter Board Connector (C).	apter board connected to the	e Balance Circuit	1
Press the <b>Jog Dial</b> to go to the next menu.	other batteries relative to their capacities. Furthermore, lead acid batteries can't be charged at a level greater than 1/10 their capacity	<ul> <li>C. Granging at a rate of 0.4A (400mAril)</li> <li>D. Voltage being applied to the battery is currently 12.39V</li> <li>F. Present above lovel of the battery is 1000mAril</li> </ul>	Press the <b>Mode key</b> until you re locate the PROGRAM SELECT LL	ach the 9 main menus, then BATT METER screen Press	rotate the <b>Jog Dial</b> t	0
	For example, a 5000mAh lead acid battery carit be charged at a rate greater than	<ul> <li>F. Time elapsed since the charge process started is 22:43</li> </ul>	LI BATT METER.			At this point, you c voltage as well as t
	0.5A. For more details on the charge and discharge capabilities of your battery, please refer to the charging data supplied by the battery manufacturer.	During charging, the <b>Jog Dial</b> can be rotated counterclockwise to show several	In a few moments, the charger w the following format:	ill begin to display the cell v	oltages of the battery	
	Correctly connect your Pb battery to the charger. Press the <b>Jog Dial</b> and adjust the charging parameters as needed. Press and hold the <b>Jog Dial</b> (approximately 3)	Safety Timer Status, Temperature Cutoff and Input Power Voltage, Capacity Cutoff, and when the pheritage of the constraints and the constraints of the constraints o	3 70 3	20 0 C		L.d.
To select values other than the existing parameter:	seconds) until the screen changes to start the battery check/charge sequence.	CAUTION: The Pb program menus are to be used ONLY for the charging	0.10 0 00 0	)./0 0.0 ) 00 0 0		11-1-1
<ul> <li>Press the Jog Dial so the cycle type (A) flashes</li> <li>Rotate the Jog Dial to set the cycle type as CHG&gt;DCHG or DCHG&gt;CHG</li> </ul>	(information may vary).	and discharging of Pb battery packs. The charging of other battery types using these programs will result in damage to the battery or charger.		/*CC C*C		You may exit this m
<ul> <li>Press the Jog Dial to save your choice and the number of cycles (B) flashes</li> <li>Rotate the Jog Dial to set the cycle count between 1 to 5</li> </ul>		<b>CAUTION:</b> Using a charge rate that is not compatible with the battery capacities may result in damage or malfunction of the charger or				menus.
<ul> <li>Press the Jog Dial to save the cycle count value</li> <li>If no parameters are flashing, you can rotate the Jog Dial to select another program</li> </ul>		batteries.	<b>38</b> USB ACCESSORY CHA	RGER OPERATION (COMPA	ATIBLE WITH iPhone	AND iPod DEVICES)
such as CHARGE, Auto CHARGE, DISCHARGE or RE-PEAK.			The Passport Ultra Duo charger h simply connect a compatible cha	has the capability to charge y	/our iPhone, iPod or U	SB compatible device v charger is powered OI
to start cycling, press and hold the <b>Jog Dian</b> for 3 seconds.	<b>33</b> PB CHARGING		5V DC.		onargo por unio are	
	Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial	To select values other than the existing parameters:	<b>39</b> TROUBLESHOOTING G	UIDE		
	to locate the PROGRAM SELECT Pb BATT screen. Press the <b>Jog Dial</b> to go into this menu.	<ul> <li>Press the Jog Dial so the charge current value (A) flashes</li> <li>Rotate the Jog Dial to INCREASE OR DECREASE the charge current value</li> </ul>	LCD Screen Warning and Error m	nessages shown below.		
	Rotate the <b>Jog Dial</b> to go to the Pb CHARGE screen and set charging parameters. The charging amperage <b>(A)</b> can be set between 0.1 and 10.0A.	<ul> <li>Press the Jog Dial to save the charge current value and the battery voltage value (B) flashes</li> </ul>	During charger operation, circuits If the message continues after vo	s monitor battery and charge ou respond as recommended	r functions. If the follo , contact your neares	owing messages show of the test of
		<ul> <li>Rotate the Jog Dial to INCREASE OR DECREASE the battery voltage/cell count value (Pb batteries are 2.0V per cell, for a 6 cell battery this would be 2.0V x 6</li> </ul>	REVERSE POLARITY	Make sure each connection	polarity is correct betwe	en the power source and
parameter messages on the LCD screen, including: Ni-Cd Sensitivity, Input Power		cell = 12.0V)  Press the <b>Jon Dial</b> to save the voltage	CONNECTION BREAK	Make sure the power connect	tions are correct for ch	arging
. Voltage, External & Internal Temperature, Temperature Cutoff, Safety Timer Status and Capacity Cutoff. The charger signals when the charging (or discharging) process	0.1H 2.00 (1F)	If no parameters are flashing, you can rotate the <b>Jog Dial</b> to select another program	SHORT ERR	Make sure there are no short Input voltage to the charger f	circuits between the po ell below the default or	oles of the battery or the l adiusted input voltage set
is complete (if Buzzer is set to ON).	Á B	such as DISCHARGE. To start charging, press and hold the <b>Jog Dial</b> for 3 seconds.	INPUT VOL EKK	input voltage.		
charging and discharging of Ni-Cd battery packs. The charging of other	04		VOL SELECT ERR	specifications or replace the	battery.	) of a lithium battery. Mak
battery types using these programs will result in damage to the battery or charger.	<b>34</b> PB DISCHARGING	To callect values other than the existing parameters:	BREAK DOWN	Charger electronics require r	epair.	oborgor Adjust sottings
<b>CAUTION:</b> Using a charge rate that is not compatible with the battery capacities may result in damage or malfunction of the charger or	to locate the PROGRAM SELECT Pb BATT screen. Press the <b>Jog Dial</b> to go into this	<ul> <li>Press the Jog Dial so the discharge current value (A) flashes</li> </ul>	BATTERY CHECK HIGH VOLTAGE	Battery voltage is higher than	the value setting in the	charger. Adjust settings, charger. Adjust settings,
batteries.	Rental. Rotate the <b>Jog Dial</b> to go to the Pb DISCHARGE screen and set discharging param-	<ul> <li>Rotate the Jog Dial to INCREASE OR DECREASE the discharge current value</li> <li>Press the Jog Dial to save the value and the cutoff voltage value (B) flashes</li> </ul>	Battery Type	Li-Po	Li-lo	Li-Fe
	eters. The discharging amperage (A) can be set between 0.1 and 5.0A. A battery's capacity can be verified by discharging it to its minimum voltage level	<ul> <li>Rotate the Jog Dial to INCREASE OR DECREASE the cutoff voltage</li> <li>Press the Jog Dial to save the voltage value</li> </ul>	Standard voltage (Volts per cell)	3.70	3.60	3.30
	and measuring the current as the battery is discharged. The discharge level can be set from 2 to 20V	If no parameters are flashing, you can rotate the <b>Jog Dial</b> to select another program such as $CHARGE$	Min. voltage (Volts per cell)	3.00	3.00	2.00
		To start discharging, press and hold the <b>Jog Dial</b> for 3 seconds				
	0.1H $2.00(1P)$					
	Å Å					
<ul> <li>Press the Jog Dial so the charge current value (A) flashes</li> </ul>	35 BATTERY MEMORY					
<ul> <li>Rotate the Jog Dial to INCREASE OR DECREASE the charge current value</li> <li>Press the Jog Dial to save the value</li> </ul>	Press the Mode key until you reach the 9 main menus, then rotate the Jog Dial to	Rotate the Jog Dial to select SAVE PROGRAM				
If no parameters are flashing, you can rotate the <b>Jog Dial</b> to select another program	locate the PROGRAM SELECT BATT MEMORY screen. Press the <b>Jog Dial</b> to select BATT MEMORY.	<ul> <li>Press the <b>Jog Dial</b> to save the program</li> <li>Repeat this process to enter additional battery profiles</li> </ul>				
such as Auto CHARGE, DISCHARGE, RE-PEAK of CYCLE. To start charging, press and hold the <b>Jog Dial</b> for 3 seconds.	Use this menu to create a battery profile. To reduce the time required to initiate a	Press the Mode key until you reach the 9 main menus				
	designed with the capability of storing up to 10 battery profiles that can be quickly	<b>CAUTION:</b> Increasing the TVC value beyond the default settings may result in a shorter battery life and/or damage to the battery. Do not change the TVC value				
	<ul> <li>Rotate the Jog Dial to identify a battery profile, 1 through 10</li> </ul>	unless you fully understand the effects IVC will have on your battery.				
	<ul> <li>Press the Jog Dial to select battery profile 1</li> <li>Press the Jog Dial so battery type flashes</li> </ul>	Press the <b>Mode key</b> until you reach the 9 main menus, then rotate the <b>Jog Dial</b> to				
	<ul> <li>Rotate the Jog Dial to select a battery type</li> <li>Press the Jog Dial to save the battery type</li> </ul>	locate the PROGRAM SELECT BATT MEMORY screen. Press the <b>Jog Dial</b> to select BATT MEMORY.				
To select a value other than the existing parameter: • Press the <b>Jon Dial</b> so the charge current value <b>(A)</b> flashes	Follow this process using the <b>Jog Dial</b> to select, change, then save each parameter (battery voltage, charge current, discharge current, discharge voltage, Terminal Volt-	<ul> <li>Rotate the Jog Dial to identify the battery profile, 1 through 10.</li> <li>Press and hold the Jog Dial for 3 seconds</li> </ul>				
Rotate the Jog Dial to INCREASE OR DECREASE the charge current value	age Control (TVC) and temperature cutoff). Then save the battery profile.	Rotate the <b>Jog Dial</b> to choose the type of charge function you wish to perform     Press and hold the <b>Jog Dial</b> for 3 seconds to start				
If no parameters are flashing, you can rotate the <b>Jog Dial</b> to select another program						
such as CHARGE, DISCHARGE, RE-PEAK or CYCLE. To start charoing, press and hold the <b>Jog Dial</b> for 3 seconds	<b>36</b> SYSTEM SET					
	Press the <b>Mode key</b> until you reach the 9 main menus, then rotate the <b>Jog Dial</b> to le SYSTEM SET.	ocate the PROGRAM SELECT SYSTEM SET screen. Press the Jog Dial to select				
	Use this menu to set the "behind the scenes" operating parameters for this charger s	such as; Rest Time, Safety Timer, Capacity Cutoff, Key Beep/Buzzer, Input Power Low				
	O DECT TIME					
	Is this manu to set the Best time during each sten in a cycle When a Ni-MH or	Lise this manu to set the key heep and charger alarm huzzer at ON or OFE as				
To select a value other than the existing parameter:	Ni-CD battery is cycled (charged, discharged and charged again) it will get hot,	needed. We recommend that you keep the alarm ON so the alarm will sound when				
<ul> <li>Press the Jog Dial so the discharge current value (A) flashes</li> <li>Rotate the Jog Dial to INCREASE OR DECREASE the discharge current value</li> </ul>	cess to make sure the battery and charger are completely cooled before moving	charging is complete or if there is cause for alarm during charging. To select values other than the default parameters:				
<ul> <li>Press the Jog Dial to save the value and the cutoff voltage value (B) flashes</li> <li>Rotate the Jog Dial to INCREASE OR DECREASE the cutoff voltage</li> </ul>	on to the next part of the cycle. Default time is 10 minutes, but this can be set between 1 and 60 minutes. To select a value other than the default parameter:	<ul> <li>Press the Jog Dial so the Key Beep ON/OFF value flashes</li> <li>Rotate the Jog Dial to select ON or OFF</li> </ul>				
Press the <b>Jog Dial</b> to save the voltage value     If no parameters are flashing, you can rotate the <b>Jog Dial</b> to select another program	<ul> <li>Press the Jog Dial to select Rest Time</li> <li>Press the Jog Dial so the Rest Time value flashes</li> </ul>	<ul> <li>Press the Jog Dial to save the value</li> <li>Press the Jog Dial so the Buzzer ON/OFF value flashes</li> </ul>				
such as CHARGE, Auto CHARGE, RE-PEAK or CYCLE.	Rotate the <b>Jog Dial</b> to select the Rest Time in Minutes     Press the <b>Log Dial</b> to select the Rest Time value	Rotate the Jog Dial to select ON or OFF     Prose the log Dial to select ON or OFF				
Io start discharging, press and hold the <b>Jog Dial</b> for 3 seconds	<ul> <li>Rotate the Jog Dial to sale the Next Time value</li> <li>Rotate the Jog Dial to select SAFETY TIMER</li> </ul>	<ul> <li>Rotate the Jog Dial to save the value</li> <li>Rotate the Jog Dial to select Input Power Low Cutoff</li> </ul>				
	L.					
	SAFETY TIMER	Use this menu to set the input voltage limit so an alarm will sound if the voltage				
	Use this menu to set a time limit for charging a battery. When a charge cycle is started, a clock inside the charger will begin recording the elapsed charge	goes below the cutoff value. The voltage alarm value can be set anywhere from 10.0 to 11.0V				
	time. If the SAFETY TIMER function has been turned ON, the charger will stop the charging process once this time limit has been reached to avoid damage	To select a value other than the default parameter:				
To select a value other than the existing parameter:	caused by over-charging the battery. This time value can be set between 1 and 720 minutes.	<ul> <li>Press the Jog Dial so the voltage value flashes</li> <li>Rotate the Jog Dial to select the voltage value</li> </ul>				
Rotate the Jog Dial to INCREASE OR DECREASE the value	To select values other than the default parameters:	<ul> <li>Press the Jog Dial to save the value</li> <li>Rotate the Jog Dial to select External and Internal Temperatures</li> </ul>				
<ul> <li>Press the Jog Dial to save the value</li> <li>If no parameters are flashing, you can rotate the Jog Dial to select another program</li> </ul>	<ul> <li>Press une Jog Dial so une UN/UFF value flashes</li> <li>Rotate the Jog Dial to select ON or OFF</li> </ul>					
such as CHARGE, Auto CHARGE, DISCHARGE or CYCLE.	<ul> <li>Press the Jog Dial to save the value</li> <li>Rotate the Jog Dial to select the value for time</li> </ul>	EXTERNAL AND INTERNAL TEMPERATURES				
י הספר שום שיש שומו גם שם גם ווכאו וופווע.	<ul> <li>Press the Jog Dial to save the value</li> <li>Rotate the Jog Dial to select Capacity Cutoff</li> </ul>	By selecting the External and Internal Temperatures Screen you can view the				
		The optional temperature sensor (DYN5033) is required for external temperature				
	Use this menu to set a capacity limit at which the charger will stop charging a	measurement.				
To select values other than the existing parameter:	battery. When a charge cycle starts, the charger records the battery capacity. When the Capacity Cutoff function is set at ON, the charger will stop charging at	RESET FACTORY SETTINGS				
<ul> <li>Press the Jog Dial so the cycle type (A) flashes</li> <li>Poteta the Jog Dial to get the cycle and a cycle of the Dial of the cycle of the</li></ul>	the capacity limit to prevent battery damage. Capacity can be adjusted between 100 and 50,000mAh.	Press the Jog Dial to reset the charger to factory settings     Press the Jog Dial to relative VEDCION				
<ul> <li>notate the <b>Jog Dial</b> to set the cycle type as CHG&gt;DCHG of DCHG&gt;CHG</li> <li>Press the <b>Jog Dial</b> to save your choice and the number of cycles (B) flashes</li> <li>Botate the <b>Jog Dial</b> to set the cycle count between 1 to 5.</li> </ul>	<ul> <li>Press the Jog Dial so the ON/OFF value flashes</li> <li>Rotate the Jog Dial to select ON or OFF</li> </ul>	- TIESS UIE SUY DIAL U SEIEL VENOIUIY				

VERSION

By selecting the Version Screen you can view the version (revision number) of the software on your charger.

You may exit this menu at any time by pressing the **Mode key** to return to the main menus.

• Press the **Jog Dial** to save the value

• Press the Jog Dial to save the value

Rotate the Jog Dial to select Key Beep/Buzzer

• Rotate the **Jog Dial** to select the Capacity Cutoff value

©2013 Horizon Hobby Inc

Dynamite, Passport, EC3 and the Horizon Hobby logo are trademarks or registered trademarks of Horizon Hobby, Inc. iPhone and iPod are trademarks of Apple, Inc., registered in the U.S. and other countries. Microsoft®, Windows XP® and Windows Vista® are registered trademarks of the Microsoft Corporation. Created 10/12



You may exit this menu at any time by pressing the Mode key to return to the main

B compatible device with the 1A USB charge port (E). To use the charging function, charger is powered ON. The internal USB charge port will provide up to 1A current at

ving messages show on the charger's LCD screen, make the recommended responses Horizon Hobby customer service center for assistance.

the power source and the charger, then between the charger and the battery

es of the battery or the battery and the charger. Replace damaged wires. justed input voltage setting. Make sure the power source for the charger provides correct

of a lithium battery. Make charger settings match the battery pack label cell in series count

## narger. Adjust settings, then make sure the battery is not damaged or replace the battery. harger. Adjust settings, then make sure the battery is not damaged or replace the battery.

Ni-MH	Ni-Cd	Pb
1.20	1.20	2.00
1.60	1.60	2.45
1.00	0.85	1.75