



## Aton Plus (7909) Parts List

Parts shown in bold are optional accessories. Part categories and individual part listings are arranged alphabetically.

### Canopies & Blades

7913	Canopy, front, black/white, Aton
7912	Canopy, front, blue/white, Aton
7914	Canopy, front, green/white, Aton
7911	Canopy, front, red/white, Aton
7916	Canopy, rear, black, Aton
7919	Canopy, roll hoop, blue
7921	Canopy, roll hoop, green
7920	Canopy, roll hoop, orange
7918	Canopy, roll hoop, red
7922	Canopy, roll hoop, white
7981	Decals, high visibility, blue
7983	Decals, high visibility, green
7982	Decals, high visibility, orange
7980	Decals, high visibility, red
7984	Decals, high visibility, white
7926	Rotor blade set, black (2) (with screws)
7929	Rotor blade set, blue (2) (with screws)
7931	Rotor blade set, green (2) (with screws)
7930	Rotor blade set, orange (2) (with screws)
7928	Rotor blade set, red (2) (with screws)
7927	Rotor blade set, white (2) (with screws)
7942	Wrench, rotor blade, 2mm (hex)

### Hardware

3229	Screws, 2.5x10mm cap-head machine (hex drive) (6)
7944	Screws, 2.6x5mm button-head, self-tapping (hex drive) (6)
7943	Screws, 2.6x8mm button-head, self-tapping (hex drive) (6)

### Main Frame & LED Lenses

7972	Damper balls, anti-vibration, gimbal (4) (yellow dot)/ camera mount (4)
7949	Feet, non-skid, LED lens (4)/ landing gear (4)
7970	Gimbal, 2-axis
7973	Landing gear, tall
7952	LED lens, front, blue (left & right)
7950	LED lens, front, clear (left & right)
7954	LED lens, front, green (left & right)
7953	LED lens, front, orange (left & right)
7951	LED lens, front, red (left & right)
7962	LED lens, motor, blue (left & right)
7960	LED lens, motor, clear (left & right)
7964	LED lens, motor, green (left & right)
7963	LED lens, motor, orange (left & right)
7961	LED lens, motor, red (left & right)
7957	LED lens, rear, blue (left & right)
7955	LED lens, rear, clear (left & right)
7959	LED lens, rear, green (left & right)
7958	LED lens, rear, orange (left & right)
7956	LED lens, rear, red (left & right)
7923	Main frame (black)
7924	Main frame, lower (black)
7925	Main frame, upper (black)
7971	Mount, camera/gimbal (anti-vibration)

### Motors & Electronics

7970	Gimbal, 2-axis
7947	LED light harness, front
7948	LED light harness, rear
7934	Motor, brushless

### Radio System, Batteries & Chargers

2831X	5000mAh 11.1v 3-Cell 20C LiPo Battery
<b>2832X</b>	<b>5000mAh 11.1v 3-Cell 25C LiPo Battery</b>
2948	Charger, 2-3 Cell LiPo Balance
<b>2972</b>	<b>Charger, EZ-Peak Dual, 100W, NiMH/LiPo with iD Auto Battery Identification</b>
<b>2970</b>	<b>Charger, EZ-Peak Plus, 4 amp, NiMH/LiPo with iD Auto Battery Identification</b>
6640X	Gimbal sticks, transmitter (thumb pads)
7939	Transmitter, Aton

If you have questions or need technical assistance, call Traxxas at:

**1-888-TRAXXAS**

(1-888-872-9927) (U.S. residents only)

For orders, calls outside the U.S., and other information, call 972-549-3000, or fax to 972-549-3011 e-mail [support@Traxxas.com](mailto:support@Traxxas.com)

**TRAXXAS.COM**